



Threading the upper shoulder plate:

Threading the upper shoulder plate to avoid getting the webbing bound up is very simple. Here is a simple step by step procedure.

1. After finding the halfway point on the continues piece of webbing. Thread the webbing diagonally through the slot so that the halfway point meets up with the hole on the upper plate for a book screw. *Figure (1a).*
2. Fold the webbing over and continue to thread the webbing out of the remaining slot. You may now burn a hole in the webbing that overlaps each other and install a book screw to keep the webbing from shifting through the upper plate. *Figure's (1b and 1c).*



Figure 1a.



Figure 1b.



Figure 1c.